

WINGS

- Thickness and width of wing work hand in hand
- More thickness = less width
- Less thickness = more width
- Center of wing/stake typically will be on outside edge of wire
- Wing dimensions can be to the center of the wing, but for function should be dimensioned to the edges of the wing
- Wings typically are centered on the wire (see front view)
- Radial wing location to be held $\pm 5^\circ$

