

PUNCH BREAK OUT

Punch flare out will start approximately at the mid point of the flat and will flare out to ~12% of the flat thickness + the desire features size

(This holds true for all shapes of punched holes)

